



1. Before assembling as shown ensure that rubber 'O'rings are in place.
2. Assemble hand tight with sprays positioned correctly before using spanner provided to lock up.
3. Ensure that the hose is fully un-rolled with no kinks before turning on water supply
4. Turn on water supply, lower lid down until it sits on pedal.
5. Your shower is now ready for use by stepping on box lid.
6. After use dry unit before packing away.

## ***SHOWERS & EYEBATHS***

Unit23C Sandwash Close, Rainford Industrial Estate, Rainford, WA11 8LY  
 (+44) (0) 1744 889677 Fax (+44) (0) 1744 885663

<b>TITLE</b>		GPSS PORTABLE STAINLESS SHOWER			
Drg. No.	1112	Drawn	A Yates	Date	<b>MAY97</b>
Revision		Date			